



Template for Measuring Blade Angle



1. Hold the rotor hub over the template, and look straight down from above. Adjust its position, so that:
 - the turbine axle is over the horizontal line
 - the centre of the yellow hub wheel is over the centre of the circle.
2. Turn the turbine hub until the top blade is vertical.
3. Look down and twist the blade until it lies along the ruler's edge.
4. Turn the hub again until the next blade is at the top. Repeat the process, until all the blades have the same pitch.